

USER MANUAL

2.7K HD Thumb Camera



Camera Exterior Structure



Standard Accessories

| Accessories | Description | Illustration |
|-----------------------|--|--------------|
| Momoic back | Please place the magnetic neck mount inside the clothing with the magnetic back clip attaching to the silicone side, and place the camera on the magnetic back clip. ----- Charging after an arm or shield and use this product. It is recommended to use a lanyard. | |
| Type-C Charging Cable | Charge the camera | |
| Lanyard | Secure the camera to prevent it from falling | |

Camera Charging/Power On:

Charge the camera using the Type-C charging cable included in the package. During charging, the camera's status indicator will show a red light, and once fully charged, the status light will turn off.

Betriebsanzeige:

The red status indicator for video recording and photography. It blinks once per second during video recording.

Charging time: 90 minutes Battery life: 100 minutes

Button Operation

1、Power Button:

- When powered off, press and hold the power button to turn the device on or off.
- During recording mode, a short press starts or pauses recording. During photo mode, a short press takes a photo.
- Within the menu system, it functions as the confirmation key.

2、M (Menu) Button:

When in standby mode, a short press of the M button enters the settings menu. Within the menu, press the WIFI button to move the selection up, press the M button to move the selection down, and press the power button to confirm your selection. Press and hold the WIFI button to exit the menu.

WIFI Button

- Press and hold the WIFI button to enter or exit the camera's WIFI mode.
- During recording, a short press locks the current file, preventing it from being overwritten during loop recording.
- Within the menu system, press and hold the WIFI button to exit.
- In standby mode, a short press of the WIFI button toggles between Recording, Photo, and Playback modes; a short press of the power button takes a photo; press and hold the WIFI button to exit.
4. Insert Card: Open the TF card silicone cover and insert the TF card in the correct direction as indicated.
5. Adjustable Lens Angle: The built-in camera can be flipped upward by 180 degrees to meet various shooting needs.
6. Freeze: If the unit freezes, press and hold the power button for 10 seconds to reset.



Scan the QR code to download the "Viidure" APP

Connect the camera's Wi-Fi to the mobile app

- Scan the QR code to download the "Viidure" APP, then press and hold the WIFI button to turn on WIFI.
- Find the WIFI name: D1***** in the phone's WIFI list and enter the password: 12345678 to connect.
- Open the 'Roadcam' app, tap the camera icon on the homepage, and follow the on-screen instructions to connect.

Video Recording Mode Menu

| | |
|--------------------------|---|
| Video Resolution | 2.7K/1080P/720P |
| Photo Resolution | 1.3M/2M/3M/5M/8M/10M/12M/VGA |
| Time-Lapse Recording | Off / 1 sec / 2 sec / 5 sec |
| Loop Recording | Off / 1 min / 2 min / 5 min |
| Date/Time | Set year, month, day, hour, minute, and second. Use the WIFI button to adjust the current selection upwards, or the M button to adjust downwards. Press the Power button to confirm and proceed to the next item. Press and hold the WIFI button to save settings and exit. |
| Auto Power off | Off/1 minutes/3 minutes |
| Auto Screensaver | Off/1 minutes/2 minutes/5 minutes |
| Language | English, Chinese (Traditional), Chinese (Simplified), French |
| Light Frequency | 50HZ/60HZ |
| Format | Cancel/Confirm |
| Restore Factory Settings | Cancel/Confirm |

Important Notes

- Automatic Stop During Recording or No Loop Recording: Due to the large size of high-definition video data, the read/write speed of the memory card may not be fast enough. Please use a high-speed TF card, such as a C10 card.
- Loop Recording Settings: If set to off, video will be recorded in 5-minute segments, and the card will not automatically overwrite when full.
- Blurry Photos: Please check if the lens has dirt or fingerprints. Clean the lens surface before shooting to ensure the lens is clean and clear.
- Inconsistent Video Quality: The video quality is greatly affected by the lighting conditions, such as backlighting, front lighting, and the strength of the light, all of which can cause variations in the video recording quality.
- Freeze: Press and hold the power button for 10s to reset.
- To Maintain Optimal Camera Performance: Do not operate the camera for extended periods (>1 hour) in environments outside the recommended temperature range or in extremely humid environments. Avoid using the camera in saunas or hot springs. Do not store the camera in high-temperature or high-humidity environments, and do not disassemble the camera.

使用说明书

2.7K 高清拇指相机



相机外观结构



标配配件

| 配件 | 描述 | 示意图 |
|------------|--|-----|
| 磁吸挂脖支架 | 请将磁吸挂脖支架放入衣服内侧，磁吸背夹与硅胶一面相吸，相机放置于磁吸背夹上。 注：佩戴心脏起搏器的患者请勿使用，建议使用挂绳。 | |
| Type-C 充电线 | 给相机充电 | |
| 挂绳 | 固定相机以免脱落。 | |

相机充电/开机：
使用包装内的 Type-C 充电线给相机进行充电。充电过程中相机的状态指示灯红灯，充满电之后状态灯熄灭。
工作指示灯：
相机充电时间：90 分钟 续航：100 分钟
按键操作
1.电源键：
A. 关机状态下，长按电源键开机和关机。
B. 开机录像模式下，短按为开启或暂停录像，拍照模式下，短按拍照。
C. 菜单模式下是确认键
2.M 菜单键
待机状态下，短按 M 键进入设置，按 WIFI 键为向上选择键，按 M 键为向下选择键，电源键为确认键。长按 WIFI 键取消菜单

3. WIFI 键

- A. 长按 WIFI 键进入或者退出相机 WIFI。
- B. 录像状态下短按 WIFI 键为文件加锁，加锁文件，不会被循环抹掉。
- C. 进入菜单后长按 WIFI 键为退出键，
- D. 待机状态下短按 WIFI 键为录像/拍照/回放切换，短按电源键为拍照键，长按 WIFI 键退出。

4. 插卡

打开 TF 卡硅胶塞，请按照正确提示方向插入 TF 卡。

5. 镜头视角可调

本机摄像头可以向上翻转 180 度满足多种拍摄需求

6. 当机：当机后请长按 10S 电源键复位。



扫码下载“录风者”APP

手机 APP 连接相机 WIFI

- 1. 下载安装“录风者”APP, 长按 WIFI 键, 打开 WIFI。
- 2. 在手机 WIFI 列表中找到 WIFI 名称: D1-*****, 需要输入密码: 12345678, 进行连接。
- 3. 打开“录风者”App, 点击首页相机图标, 连接 WIFI, 根据界面提示操作。

录像模式菜单

| | |
|--------|--|
| 录像分辨率 | 2.7K/1080P/720P |
| 拍照分辨率 | 1.3M/2M/3M/5M/8M/10M/12M/VGA |
| 缩时录像 | 关/1秒/2秒/5秒 |
| 循环录影 | 关/1分钟/2分钟/5分钟 |
| 日期/时间 | 可设置年月日时分秒，显示顺序上(WIFI键)/下(M键)键调节当前选项时间，电源键 确认并进入下一项，长按 WIFI 键保存并退出。 |
| 自动关机 | 关/1分钟/3分钟 |
| 自动屏保 | 关/1分钟/2分钟/5分钟 |
| 语言 | 英、中文(繁)、中文(简)、法 |
| 光源频率 | 50HZ、60HZ |
| 格式化 | 取消/确认 |
| 恢复出厂设置 | 取消/确认 |

注意事项

- 1. 录像时自动停止录或不循环录像由于高清视频数据巨大，有可能因为内存卡的读写速度跟不上。请使用高速 TF 卡如 C10 的高速卡。
- 2. 循环录像的设置：如果选择关闭，5 分钟一段，卡满将不能自动循环覆盖。
- 3. 拍出的照片不清晰：请检查镜头是否有脏物、手指印。进行拍摄前请清洁镜头表面，保持镜头的干净整洁。
- 4. 拍出的影片有时效果时好时坏：录像效果与拍摄的光线环境有很大关系，如逆光、顺光、光线的强弱等都会造成拍摄出来的视频效果不同。
- 5. 当机：当机后请长按 10S 电源键复位。
- 6. 为了保持相机最佳性能，请勿在温度范围外或极端潮湿的环境下长时间(>1 小时)操作本拇指相机，如桑拿房或温泉中使用，请勿在温度过高或湿度过高的环境存放，请勿拆卸相机。