SAMEUO®

WEBCAM

USER MANUAL

Thank you for choosing our newest webcam!
This is a product for real-time data transmission to PC via USB port. It has a high resolution and fast transmission rate, and it is also nice-looking and portable. This webcam enables you to share happy moments online with your family and friends!

PRODUCT DIAGRAM

①4-Array AI noise-canceling mics
②Dual 3W Hi-Fi Sperkers
③Fixed focus 2K/4K lens
④Privacy cover
⑤Tripod Screw Hole
⑥Flexible Base / Clip
⑦USB Cable
⑧User Manual



PARAMETERS AND FEATURES

- QHD2K/UHD 4K CMOS color sensor
- Interface: USB2.0 port
- Image focus: Fixed focus
- wide angle adjustable

- 4-Array AI noise-canceling mics
- Dual 3W Hi-Fi Speakers
- Social Software Compatibility
- Multi-purpose mounting clip
- Specification of tripod screw hole: 1/4" standardscrew hole
- Auto Exposure Control
- Auto White Balance
- Automatic Gain Control

SYSTEM REQUIREMENTS

- IBM PC or compatible PC or laptop with USB port
Pentium 200 or higher CPU.
Operation system:
- WINXP/Vista/Win7/Win8/Linux (version 2.6.26 or later) with UVC
Mac OS X10.4.8 or later/ Android 4.0 or above with UVC

INSTALL YOUR WEBCAM

1.Place Your Webcam

Position the webcam in your preferred location: on a computer display, desktop, or tripod.



For Placement on the Display:
Open the webcam clip, and follow the steps and methods show in the figure to place the webcam on top of the display, please make sure the clip is firmly mounted.



2.Connect the Webcam

Connect the camera to the compute via the Type-C interface.



Warm Tip: When using a desktop, it is better to connect the webcam to the USB interface on the back of the computer, because this will be much more smooth in using.

3.When installation is finished, you can start using.

REMOTE CONTROL INSTRUCTIONS

1. Quick Start Tips

. Zoom – Digital zoom is disabled when using 2K/4K resolution. Switch to 1080p or lower resolution to use the zoom function.

. Remote Operating Range – Keep the remote control within 16.4 ft (5 m) of the webcam.

. Batteries – The remote control requires 2 AAA batteries (batteries are not included).

2.Remote Control Button Functions

·PRIVACY : Disables video output (camera privacy mode)
·MUTE : Mutes webcam microphone only (speaker output remains active)
·MIRROR : Flips webcam feed horizontally
·RESET : Restores webcam/remote default settings
·BRI+/- : Adjust webcam brightness (up/down)
·SC+/- : Adjust color saturation (up/down)
·MODE : Cycles through preset image effects
·ZOOM+/-: Magnify/shrink webcam feed
·BLC : Boosts clarity in backlit environments
·HUE+/- : Adjust color tone (up/down)
·CONTRAST+/-: Adjust contrast (up/down)
·50/60HZ : Matches local power frequency (reduces screen flicker)

NOTICE

1.Do not use the product in hot, cold, dusty or humid environments.
2.Avoid touching the lens with your hands, sharp items or coarse objects; please use a clean, soft cloth when cleaning the lens
3.Avoid dropping the product as much as possible. Severe impacts from dropping may cause lens damage, device malfunction, or surface scratches

WARRANTY

1.This product is warranted only for issues caused by non-human factors. The warranty does not cover:
- Man-made damage.
- Repair or disassembled by other company's technicians.
- Damage due to dropping or impact.

2.Any problems, you can contact the seller to get the best solutions.(Information contained herein is subject to change without notice.Windows is a trademark of the Microsoft group of companies. Mac is a trademark of Apple, inc., registered in the U.S. and other countries.)